



### Fusers List

If you wish to send us any used fusers, please note:

- That they must be returned in their original boxes.
- If you have more than 5 without their original packaging, please call for advice on how to send us these items.
- All types of fusers are accepted however not all items have a value.

Description	Maintenance Kit	Fuser
HP LaserJet 1005		RG9-1494-000CN
HP LaserJet 1010/1012/1015		RM1-0661-040CN
HP LaserJet 1018		RM1-2050-000CN
HP LaserJet 1020		RM1-2087-000CN
HP LaserJet 1022		RM1-2050-000CN
HP LaserJet 1100	H3965-60002	
HP LaserJet 1150		RM1-0716-030CN
HP LaserJet 1160		RM1-2337-000CN
HP LaserJet 1200		RG9-1494-000CN
HP LaserJet 1300		RM1-0716-030CN
HP LaserJet 1320		RM1-2337-000CN
HP LaserJet m1522MFP		RM1-4721-000CN
HP LaserJet P2014		RM1-4248-000CN
HP LaserJet P2015		RM1-4248-000CN
HP LaserJet CP2025		RM1-6739-000CN
HP LaserJet 2100	H3974-60002	RG5-4133-170CN
HP LaserJet 2200	H3978-60002	RG5-5569-110CN
HP LaserJet 2300	U6180-60002	RM1-0355-050CN
HP LaserJet 2400/2410/2420/2430	H3980-60002	RM1-1537-020CN
HP LaserJet M2727		RM1-4248-000CN
HP LaserJet P3005		RM1-3741-030CN
HP LaserJet 3015/3020/3030		RM1-0866-000CN
HP LaserJet M3027x MFP		RM1-3741-030CN
HP LaserJet 3050		RM1-3045-000CN
HP LaserJet 3055		RM1-3045-000CN
HP LaserJet M3035 MFP		RM1-3741-030CN
HP LaserJet 3100	H3975-60002	RG5-4681-000CN
HP LaserJet 3200	H3965-60002	
HP LaserJet 3300/3330		RG9-1494-000CN
HP LaserJet 3380		RM1-2076-030CN
HP LaserJet 3390		RM1-2337-000CN
HP LaserJet 4000	C4118-67910	RG5-2662-500CN
HP LaserJet P4014N	CB389-67901	CB506-67902
HP LaserJet P4015	CB389A	CB506-67902
HP LaserJet 4050	C4118-67910	RG5-2662-500CN
HP LaserJet 4100	C8058-67903	RG5-5064-340CN
HP LaserJet 4200	Q2430-67905	RM1-0014-230CN
HP LaserJet 4240	C5422-67901	RM1-1083-070CN
HP LaserJet 4250	Q5422-67903	RM1-1083-070CN
HP LaserJet 4300	Q2437-67904	RM1-0102-300CN

HP LaserJet 4345	Q5999A	RM1-1044-080CN
HP LaserJet 4350	Q5422-67903	RM1-1083-070CN
HP LaserJet P4510N	CB389A	CB506-67902
HP LaserJet P4515N	CB389A	CB506-67902
HP LaserJet 5000	C4110-67915	RG5-5456-100CN
HP LaserJet M5025MFP	Q7833-67901	RM1-3008-000CN
HP LaserJet M5035MFP	Q7833-67901	RM1-3008-000CN
HP LaserJet 5100	Q1860-67903	RG5-7061-190CN
HP LaserJet 5200		RM1-2524-000CN
HP LaserJet 8000	C3972-67903	RG5-4448-R
HP LaserJet 8100/8150	C3915-67902	RG5-6533-010CN
HP LaserJet 9000	C9153-67904	
HP LaserJet 9050	C9153-67904	
HP Colour LaserJet		
HP Colour LaserJet 5 / 5M		
HP Colour LaserJet CM1015MFP		RM1-4313-000CN
HP Colour LaserJet CM1017MFP		RM1-4313-000CN
HP Colour LaserJet 1500		RG5-6913-000CN
HP Colour LaserJet CP1518NI		RM1-4431-000CN
HP Colour LaserJet 1600		RM1-1821-240CN
HP Colour LaserJet 2500		RG5-6913-000CN
HP Colour LaserJet 2550		RG5-7573-110CN
HP Colour LaserJet 2600		RM1-1821-240CN
HP Colour LaserJet 2605		RM1-1829-000CN
HP Colour LaserJet 2605DN/2605DTN		RM1-1825-000CN
HP Colour LaserJet 2820		RG5-7603-070CN
HP Colour LaserJet 2840		RG5-7603-070CN
HP Colour LaserJet 3000		RM1-2764-060CN
HP Colour LaserJet 3500		Q3656A
HP Colour LaserJet CP3505N		RM1-2764-060CN
HP Colour LaserJet 3550		Q3656A
HP Colour LaserJet 3600		RM1-2764-060CN
HP Colour LaserJet 3700		Q3656A
HP Colour LaserJet 3800		RM1-2764-060CN
HP Colour LaserJet CP4005		Q7503A
HP Colour LaserJet 4500	R96-5008-000CN	
HP Colour LaserJet 4550	R96-5008-000CN	
HP Colour LaserJet 4600		RG5-6517-230CN
HP Colour LaserJet 4650		Q3677A
HP Colour LaserJet 4700		Q7503A
HP Colour LaserJet 4730		Q7503A
HP Colour LaserJet 5500		C9736A
HP Colour LaserJet 5550		Q3985A
HP Colour LaserJet 8500		C4156A
HP Colour LaserJet 8550		C4156A
HP Colour LaserJet 9500		C8556A
HP LaserJet II/III		
HP LaserJet IIP/IIIP		
HP LaserJet IIISi/4Si		
HP LaserJet 4/4M		RG5-0455-000CN
HP LaserJet 4+/4M+		RG5-0880-130CN
HP LaserJet 4L/4P		
HP LaserJet 4V/4MV		
HP LaserJet 5/5N/5M	C3916-67913	RG5-0880-130CN
HP LaserJet 5P		
HP LaserJet 5Si/5SiMX	C3972-67903	
HP LaserJet 6L		
HP LaserJet 6P	H3967-60001	

**OEM Part Code**

**For use in Lexmark  
Printers:**

RightBrand 12G4185 Lexmark Optra W820 Fuser Assy - 126K10649	12G4185
RightBrand 99A0593 Lexmark Optra S3455 Fuser	99A0593
RightBrand 99A2404 Lexmark Optra T622 Fuser	99A2404
RightBrand 99A1585 Lexmark Optra T614/16 Fuser	99A1585
RightBrand 56P1335 Lexmark Optra T630/T632 Fuser	56P1335
RightBrand 99A2422 Lexmark Optra T520/522 Fuser	99A2422
RightBrand 99A1188 Lexmark Optra S1650/1855 Fuser	99A1188
RightBrand 56P1860 Lexmark Optra T634 Fuser Assy 220v	56P1860
RightBrand 56P0671 Lexmark Optra T420 Fuser Assy 240v	56P0671
RightBrand 99A1191 Lexmark Optra S2450/55 Fuser	99A1191
RightBrand 99A1186 Lexmark Optra S1250/55 Fuser	99A1186
RightBrand 40X2590 Lexmark Optra T640/42/44 Fuser Assy	40X2590
RightBrand 99A1661 Lexmark Optra T610/612 Fuser	99A1661
RightBrand 99A2401 Lexmark Optra T620 Fuser Assy	99A2401
RightBrand 40X4195 Lexmark E230/232/234/240/330/332/340/342	40X4195